## IMPORTANT

**1951 Lionel train outfits are designed for use with "Multi-Control" transformers which are equipped with built-in controls for operating the locomotive reversing mechanism and for blowing the train whistle. For this reason 1951 outfits do not include a separate No. 167 Whistle Controller previously furnished with all whistling outfits.**

**All "027" outfits include a No. 1033 "Multi-Control" Transformer which is suitable for operating the outfit plus a few accessories.**

**"O" outfits do not include a transformer; a separate transformer to fit the requirements of your model railroad must be purchased from your dealer.**

All Contents Copyrighted 1951 by
THE LIONEL CORPORATION
15 E. 26th Street, New York 10, N. Y.

Printed in U. S. of America
No. 926-51

# TABLE OF CONTENTS


## PART ONE
### How to Assemble and Operate Your First Lionel Outfit

**HOW TO ASSEMBLE YOUR LAYOUT** Page 3
Assembling the Track — Attaching Lockon to Track — Connecting the Wires — How an Assembled Layout Should Look

**HOW TO SET UP YOUR TRAIN** Page 5
Check and Lubricate Your Equipment — Set Up the Train — Check Your Power Supply

**HOW TO OPERATE THE TRAIN** Page 6
Changing the Train Speed — Reversing the Locomotive — How to Disconnect Reversing Mechanism — Blowing the Whistle — Flashlight Cells for Horns — "Magne-Traction" Locomotives — Smoke Locomotives — Short Circuits — Remote Control Track Sets — Coupling and Uncoupling Cars — Fixed Voltage for Remote Control Track

**AUTOMATIC OPERATING CARS** Page 10
Cars Using Contact Sliders — Plunger-Operated Cars — No. 3472 Automatic Milk Car — No. 3656 Operating Stock Car

**SPECIAL OPERATING CONDITIONS** Page 14
Use of No. 167 Whistle Controller — Direct Current Operation

## PART TWO
### How to Operate Lionel Accessory Railroad Equipment

**ABOUT LIONEL TRACK** Page 15
Lionel Track Sizes — Laying the Track — Removing Track Pins — Track Switches and Crossings

**ABOUT TRACK SWITCHES** Page 17
No. 022 Remote Control Switch — Fixed Voltage Plug — Non-Derailing Operation — Reversing Switch Motor — No. 1121 Remote Control Switch — No. 1024 and No. 042 Manual Switches

**AUTOMATIC SIGNALLING** Page 20
Using 145C Contactor — No. 252 Crossing Gate — No. 145 Gateman and No. 151 Semaphore — No. 153C Contactor and No. 153 Stop Signal — Operating Two Trains — Insulated Track Sections — No. 154 Crossing Signal — No. 1045 Flagman

**ILLUMINATED ACCESSORIES** Page 27
No. 256 Freight Shed and No. 395 Floodlight Tower — Parallel Connections

**OPERATING ACCESSORIES** Page 28
No. 97 Coal Elevator — No. 164 Lumber Loader — No. 364 Lumber Loader and No. 379 Coal Loader — No. 456 Coal Ramp — No. 213 Lift Bridge — No. 132 Automatic Station — No. 30 Water Tower — No. 394 Rotating Beacon — No. 455 Oil Derrick — Voltages Required by Accessories

**ABOUT YOUR POWER SUPPLY** Page 36
Household Power Lines — Voltages Supplied by Lionel Transformers — About Wattage — Power Requirements — About Voltage — Using Auxiliary Lockons

## PART THREE
### How to Build a Model Railroad

**PLANNING A MODEL RAILROAD** Page 39
Planning for the Future — Elevate Your Layout — Make Use of "Magne-Traction"

**FIVE INTERESTING LAYOUTS** Page 41
Making Odd-Length Track — Expanding Your Pike — "O" and "072" Layouts — Realism With Scenery — Automatic Train Operations — Running a Railroad

## PART FOUR
### How to Take Care of Lionel Equipment

**WHAT YOU CAN DO YOURSELF** Page 47
Cleaning Your Equipment— Lubricating Lionel Trains — When tot Use Lubricant — When to Use Oil — Lubricating Train Whistle — How to Clean Motors — Lubricating Car Trucks — Replacing Headlight Lamps — Replacing Horn Cells — Motor Trouble Shooting — Finding Short Circuits

**LIONEL AUTHORIZED SERVICE STATIONS** Page 53